Fuel Flush



Short Description Fuel Flush

Description

Fuel Flush absorbs residual methanol/nitro and leaves a lubricating film to protect against fuel gelling damage and corrosion. It also lubricates superchargers, valve guides, fuel pumps, barrel valves, solenoids and other fuel components to provide engine protection at start-up. On start-up Fuel Flush will readily dissolve in methanol/nitro fuels and can be rinsed off hands or components with water as required.

Give us a call to enquire about pricing and availability on 095256858