

## Injector head-pneumatic



### Description

**DJ Safety is the leader in Coldfire fire suppression systems. SFI 17.1**

We have a three injector head styles in stock including these pneumatically operated heads. A pneumatic head must be used in conjunction with a cable head to adhere to the rule that the bottles must be discharged manually. This type of head is normally used on the second bottle and has a line running from the first bottle, with the pressure from the first bottle setting of the pneumatic head.

Part Number	Description
DJ911329	Pneumatic Injector Head